

PART LIST

A x20	B x8	C x16	D x2	E x2	F x2
G x2	H x14	I x4	Tools		
D			Extra		

1 x1	2 x1	
3 x1	4 x1	
5 x1	7 x2	8 x2
6 x2		

01

2 x1 **3** x1
7 x2 **A** x8 **C** x8

02

1 x1 **6** x2
A x4 **B** x8

03

4 x1 **A** x4
C x4

04

5 x1 **A** x4
C x4

05

D x2 **E** x2
F x2 **G** x2 **H** x14

06

1 x4 **8** x2